

# MVG40 Headed Pin Valve Gate

#### Assembly Overview


#### IMPORTANT!!

The back plate must be cooled and must not exceed 150°C.


The cylinder should be in the closed position at all times except during injection and packing.

Air quality: Filtered to 40 µM and lubricated

Minimum air: pressure 4 Bar
Maximum air: pressure 10 Bar



## Spacing Layout




#### MVG40 Headed Pin Overall Dimensions

Note: Pins are supplied in standard length and must be cut to required length before installation.

Pins can be supplied finished ready to use by Mastip

ightarrow Refer to page MVG40-6 Pin Calculations section to calculate required final pin lengths



Nozzle Compatibility							
Description	Nozzle	Nozzle Length	Supplied Pin Size				
MVG40-P1 Headed Pin	MX13 / BX13	45 - 225	Ø2.0				
	MX16 / BX16	45 - 250	Ø2.5				
	MX19 / BX19	45 - 300	Ø3.0				
	BX27	75 - 450	Ø5.0				

#### Fitment





figure. 4




#### Pin Details

**Caution:** The gap between the gate and the pin in a hot state is critical. If the gap is too large there will be a poor gate vestige and drooling from the nozzle may occur. If the gap is too small, the pin can strike the gate and may decrease the gate life.

To calculate final pin length use the following equation:

MVG40-P1 - D5.0 
$$\ \$$
 Pin Length = (Y=29.00) + 10.0 + X + L4 + L + 0.05



#### Conical and Cylindrical Valve Gate Recommendations

	Conical Valve Gate	Cylindrical Valve Gate
Gate Quality	***	***
Pin Cooling	***	*
Filled Materials	*	***
Material with Small Moulding Window	*	***
Ease of Pin Setup	*	***
Ease of Gate Manufacture	***	**
Gate Life	***	*

Key	Value
*	Lowest Rating
***	Highest Rating


#### Conical Valve Gate


D	d1	d2	AF	CP	AT	qΤ	HP
2.0	1.3	1.25	1.80	8	1.30	0.8	1.0
2.5	1.8	1.75	2.30	8	1.80	1.0	2.0
3.0	2.2	2.15	2.75	8	2.20	1.2	2.5
5.0	3.5	3.45	4.65	10	3.50	2.0	3.0


The pin will form a 0.1mm deep dimple on the part.

Pin and gate to be lapped to ensure clean shutoff.

Recommended for amorphous polymers.









Cylindrical Valve Gate


Description	D	AP	BP	AF	CP	GP	qΡ	HP
MVG40-P1 Headed Pin	2.0	1.292	2.0	1.6	5	1.305	0.5	1.0
MVG40-P1 Headed Pin	2.5	1.792	2.0	2.1	5	1.805	0.7	2.0
MVG40-P1 Headed Pin	3.0	2.192	2.0	2.6	5	2.205	8.0	2.5
MVG40-P1 Headed Pin	5.0	3.492	2.5	4.4	8	3.505	1.3	3.0

The pin will form a 0.1mm deep dimple on the part.

Recommended for semi-crystalline and filled polymers.










Guided Cylindrical Valve Gate (GVG5) or YV2 Nut

Description	D	AP	BP	AF	CP	DP	GP	qΡ	HP
MVG40-P1 Headed Pin	2.0	1.292	2.0	1.70	8	1.892	1.305	0.5	1.0
MVG40-P1 Headed Pin	2.5	1.792	2.2	2.20	8	2.392	1.805	0.7	2.0
MVG40-P1 Headed Pin	3.0	2.192	2.5	2.65	8	2.892	2.205	0.8	2.5
MVG40-P1 Headed Pin	5.0	3.492	3.0	4.55	10	4.892	3.505	1.3	3.0

The pin will form a 0.1mm deep dimple on the part. Recommended for semi-crystalline and filled polymers.








#### As Supplied


#### A MVG40 CYLINDER ASSEMBLY



## B MVG40 VALVE PIN + SEAL



### Exploded Diagram



#### Note

- 1. MVG40 Spares Kit (80-000-100). Includes Seals, Circlip and Grease
- 2. Piston Hex Socket Tool (60-085-222)
- 3. Piston Extraction Tool (60-085-015)

#### Installation and Pin Adjustment Guide


#### **PRE INSTALLATION**

- 1. Verify the actuator pockets and air circuits are machined in the back plate as shown in figure 5.
- 2. Ensure there are no sharp edges or burrs in the actuator pockets.
- 3. Ensure the actuator pocket and air circuits are clean.
- 4. Cut pins to length and profile end to conical or cylindrical (refer nozzle approval drawing)
- 5. Assemble the fixed half of the mould including hot runner nozzles and manifold excluding backplate.
  - ightarrow Refer to the Technical Specifications section of the Technical Guide Pin and seal are a matched set and must remain paired.


#### **INSTALLATION**


ONE

Ensure all components are clean




Fit the Cylinder End Seal 12 to the Cylinder 11
Apply grease\* to Cylinder End Seal 12







#### Note

Mastip recommends using high temperature silicon grease






Centralise Cylinder Assembly  $\boxed{A}$  to the Actuator pocket.



Clean any residual material from the pin seal pocket and thread in the manifold.


Apply heat resistant nickel based anti-seize to the thread of the new pin seal and screw into the manifold and tighten to 20Nm.

Ensure pins slide smoothly through the pin seal after tightening.




Fit mould backplate to mould and fasten.


**Note**: If backplate location guides start to locate first, then the cylinder assembly should self locate to the manifold. However in some cases it may be necessary to move the cylinder assemblies in the actuator pocket to locate them with the manifold.









#### **PIN HEIGHT ADJUSTMENT**





THREE

Minor Adjustment





Swap Valve Pin Adjustment Packers

3, 5b, 5c & 6d to achieve small
pin adjustments (different packer =
different height)

FOUR

Major Adjustment







Move one or more Valve Pin

Adjustment Packers 5a, 5b, 5c

& 5d from below the pin head to
above the pin head to achieve large pin
adjustment





System Overview MVG40 Headed Pin Valve Gate



#### Mastip Head Office New Zealand

**Physical Address** 558 Rosebank Road, Avondale Auckland 1026, New Zealand

**Postal Address** PO Box 90651, Victoria St West Auckland 1142, New Zealand

Phone: +64 9 970 2100 Email: mastip@mastip.com

#### Mastip Regional Office Europe

Phone: +33 0 809 400 076 Email: mastip@mastip.eu

# Mastip Regional Office North America Phone: +1 262 644 9400

Email: northamerica@mastip.com

#### Mastip Regional Office China

Email: china@mastip.com

For a full list of Distributors, please visit www.mastip.com